



Scan this code to get the most updated manual.

INSTALLATION, OPERATION & MAINTENANCE MANUAL



MODELS:

**HD2P-12KMSC
12,000 LB CAPACITY 2 POST LIFT**

! FOLLOW THIS MANUAL CAREFULLY TO ENSURE THE EQUIPMENT WILL FUNCTION CORRECTLY AND PROVIDE MANY YEARS OF DEPENDABLE SERVICE. FAILURE TO FOLLOW THESE INSTRUCTIONS AND SAFETY WARNINGS MAY RESULT IN PERSONAL INJURY OR PROPERTY DAMAGE. KEEP THIS MANUAL IN A SAFE DRY PLACE FOR FUTURE REFERENCE.



**Products May Be
Upgraded Without Notice
Please Visit**

WWW.TITANLIFTS.COM

**For The Latest Version Of
This Manual**

CONTENTS

1-SAFETY	1
1.1 INTRODUCTION.....	1
1.2 SAFETY INSTRUCTIONS FOR COMMISSIONING.....	1
1.3 SAFETY INSTRUCTIONS FOR OPERATION.....	1
1.4 SAFETY INSTRUCTIONS FOR MAINTENANCE	3
1.5 RISKS	3
2-DESCRIPTION	4
3-UNPACKING & SETUP	5
3.1 DELIVERY AND CHECK OF PACKAGES	5
3.2 LIFTING AND HANDLING.....	5
3.3 PREPARATION	5
4 SPECIFICATIONS	6
5-FLOOR REQUIREMENTS	6
5.1 SELECTING THE SITE AREA	6
5.2 FLOOR REQUIREMENTS	6
5.3 IMPORTANT CONCRETE AND ANCHORING INFORMATION	7
5.4 ANCHORING TIP SHEET	7
6-INSTALLATION INSTRUCTIONS	8
7-OPERATION INSTRUCTIONS	25
7.1 DEFECTS / MALFUNCTIONS.....	25
7.2 CONTROLS.....	25
7.2.1 UP CONTROL.....	25
7.2.2 SAFETY LOCK CONTROL.....	25
7.2.3 LOWERING CONTROL	26
7.3 OPERATION.....	26
8-MAINTENANCE	28
8.1 MAINTENANCE SCHEDULE	28
8.1.1 DAILY	28
8.1.2 WEEKLY	28
8.1.3 MONTHLY.....	29
8.1.4 BIMONTHLY	29
8.1.5 YEARLY	29
8.1.6 EVERY OTHER YEAR.....	29
8.2 MAINTENANCE BY OPERATOR	30
8.2.1 HYDRAULIC SYSTEM	30
8.2.2 GREASING POINTS.....	30
8.2.3 OPERATION AND WEAR CHECKS	31
8.2.4 LIFT STABILITY	31
8.3 CLEANING	31
9-TROUBLESHOOTING	32
10-OWNER/EMPLOYER RESPONSIBILITIES	33
11-DIAGRAMS (FIG. 1-10)	34



TITAN MARKETING, LLC

PO Box 7069 Greenwood, IN 46142
1.888.908-4826 FAX (317) 215.2770
www.titanlifts.com

To Our Valued Customers:

Thank you for purchasing a Titan Lifts® product. We hope this high quality equipment provides you with years of dependable service.

It is unfortunate that rare situations may occur with the products you purchase from Titan Lifts®. We value your business as well as the trust you have and need to maintain your relationship with us. Titan Lifts® carries liability coverage that may protect our customers if a situation does occur. However, as in all accidents there must be proof of liability for a claim to be made. Our insurance company requires the following procedures be observed in order to consider a claim:

- A. The claimant must contact the Titan Lifts® distributor immediately with the facts of the situation.
- B. If any equipment is damaged, including vehicles or shop equipment, Titan Lifts® must be given the opportunity to send an impartial representative to the site for proper assessment of the situation.
- C. The Vehicle cannot be moved until either an impartial representative has reviewed the accident or clear and precise pictures are taken that reflect all the pertinent information for an impartial representative to be able to access the information from a distance. Titan Lifts® or its representatives must approve the pictures before anything can be moved.
- D. If any potential liability is determined on behalf of Titan Lifts®, two estimates must be submitted for damages to be reimbursed.

It is imperative that the claimant complies with these procedures, because without proper assessment of the situation a claim will be denied.

ARBITRATION NOTICE

The installation or use of this equipment shall constitute an acknowledgement that the user agrees to resolve any and all disputes or claims of any kind whatsoever, which relate in any way to the equipment, by way of binding arbitration, not litigation. No suit or legal action may be filed in any state or federal court. Any arbitration shall be governed by the Federal Arbitration Act, and administered by the American Mediation Association, Indianapolis Indiana. The maximum amount that an arbitrator may award and all damages shall not exceed the retail value of this equipment.

WARRANTY NOTICE

This equipment must be assembled and used in the manner according to the documentation provided to be covered by warranty.


Damaged or missing components must be reported within 72 hours of receipt to your freight carrier and to the distributor. Claims must be filed to cover cost.

If you have any questions or if we can be of any further assistance, please don't hesitate to contact a Titan Lifts® representative at 1-888-908-4826. Thank you for the opportunity to continue to serve your lift equipment needs.

INSTRUCTIONS

1-SAFETY

1.1 INTRODUCTION

 **WARNING:** READ ENTIRE MANUAL AND COMPLY WITH ALL SAFETY AND SERVICE PRECAUTIONS. DEATH, PERSONAL INJURY AND / OR PROPERTY DAMAGE MAY OCCUR IF INSTRUCTIONS ARE NOT FOLLOWED CAREFULLY.

Personal injury and property damage incurred due to non-compliance with these safety instructions are not covered by the product liability regulations.

SYMBOLS

 **FAILURE TO COMPLY WITH INSTRUCTIONS COULD RESULT IN PERSONAL INJURY.**

 **FAILURE TO COMPLY WITH INSTRUCTIONS COULD RESULT IN PROPERTY DAMAGE.**

 **IMPORTANT INFORMATION**


1.2 SAFETY INSTRUCTIONS FOR COMMISSIONING


- The lift may be installed and commissioned by authorized service personnel only.
- The standard lift version may not be installed and commissioned in the vicinity of explosives or flammable liquids, outdoors or in moist rooms (e.g. car wash).


1.3 SAFETY INSTRUCTIONS FOR OPERATION


- Read this entire manual.
- Load should not exceed rated capacity for this lift –12,000 lbs. (3,000 lbs per lift arm)
- Only trained authorized personnel over the age of 18 years should operate the lift.
- Indoor use recommended.
- Always lift the vehicle using all four arms.
- Never use the lift to raise one end or one side of vehicle.

- Maintain a safe working environment. The work area should be clean, dry, clutter free, and sufficiently lit.
- Vehicle doors should be closed during the raising and lowering cycles.
- Closely watch the vehicle and lift during the raising and lowering cycles.
- Do not operate the lift in explosive atmospheres, such as in the presence of flammable liquids, gases, or dust. Power equipment can create sparks which may ignite flammables.
- Keep hands, tools, and other extremities from under carriage and moving parts.
- Never operate this lift with someone on it.
- Do not allow anyone on the lift or inside a raised vehicle.
- Keep children and bystanders away from work area. Do not let children operate or play on lift.
- Wear proper safety attire. Do not wear loose fitting clothing while operating lift. Long hair, jewelry and sleeves should be secured.
- Never leave the lift unattended while under a load.
- Do not operate this lift if under the influence of drugs, alcohol, or medication. Operator must be alert at all times when using heavy lift equipment.
- Comply with all applicable accident prevention regulations.
- Only use the vehicle manufacturer's recommended lifting points.
- After positioning the vehicle, apply the parking brake.
- Use caution when removing or installing heavy vehicle components which may result in center-of-gravity displacement.
- Use this lift only for the work it is intended. Do not use this product for an application for which it was not designed. Misuse can lead to personal injury and/or property damage.

 **WARNING:** Prior to completely raising the vehicle, raise the vehicle 6" off the ground and check the adapter pads for solid contact by performing the "BUMPER TEST". Walk around the back of the vehicle and push up and down on the bumper. The vehicle will rock, but should not at any time lose contact with the pads. If the vehicle is bouncing off the pads or feels at all unstable, you should lower it back to the ground and reposition the pads to balance the load. Repeat this process until the vehicle is completely stable.

 **WARNING:** Use this lift only in well ventilated areas. Carbon monoxide exhausted from running vehicle engines is a colorless, odorless fume that, if inhaled, can cause serious personal injury or death.

 **WARNING:** People with pacemakers should consult their physician(s) before using this product. Operation of electrical equipment in close proximity to a heart pacemaker could cause interference or failure of the pacemaker.

 **WARNING:** This product contains or produces a chemical known to the State of California to cause cancer and birth defects (or other reproductive harm). (California Health & Safety Code 25249.5 et seq.)

1.4 SAFETY INSTRUCTIONS FOR MAINTENANCE

- Maintenance or repair work should be done by authorized service personnel only.
- Work on the electrical equipment should be done by certified licensed electricians only.
- Ensure that ecologically harmful substances are disposed of in accordance with the appropriate regulations.
- To prevent the risk of damage, do not use high pressure / steam jet cleaners or caustic cleaning agents.
- Do not replace or override the safety devices.

1.5 RISKS



WARNING: Risks the personnel could encounter, due to an improper use of the lift, are described in this section.

CRUSHING RISK

During lowering of runways and vehicles, personnel must not be within the area covered by the lowering trajectory. The operator must be sure no one is in danger before operating the lift. Stay clear of the lift when lowering or raising vehicles. Keep hands and feet away from moving parts and especially points that could pinch. Keep your feet clear of the lift when raising and lowering vehicles.

BUMPING RISK

When the lift is stopped at relatively low working height, the risk of bumping against projecting parts increases. Always be aware of your surroundings and avoid bumping your head or body on the lift or the vehicle.

RISK OF THE VEHICLE FALLING FROM THE LIFT

Risk of the vehicle falling from the lift is increased: when the vehicle is improperly placed on the platforms, when the vehicle's weight or physical dimensions exceed the rated capacity of the lift, or when there is excessive movement of the vehicle while on the lift. If vehicle appears to begin falling, exit the area as quickly as possible to avoid injury. Always position vehicle with the center of gravity midway between the adapters. Adding or removing parts of a vehicle on the lift will alter the weight displacement on the lift. Therefore, use of auxiliary safety stands in the front and back of the vehicle is recommended. Never override the manufactured lift controls. Always use height adapter pads when possible to ensure proper contact. Only authorized personnel should be allowed in the lift area and the lift should only be operated by authorized and trained personnel. Adding or removing parts of a vehicle on the lift will alter the weight displacement on the lift.

2-DESCRIPTION


HD2P-12KMSC- Heavy Duty, 2-post, 12,000lb capacity, Master Series, Clear-floor lift with symmetric arms

This lift is a 12,000 lb. capacity, 2-Post Lift. The safety latch system is very similar to an extension ladder. The safety latch is manually released by a single lever and the spring-loaded locks engage into place as the carriages are raised. The safety locks must be manually disengaged for the lift to descend. If the user lets go of the manual release handle, the safety latch will re-engage on the next lock latch below. Due to the "Direct Drive" hydraulic system, this lift does not have the typical chain-over-roller style cylinder. Each cylinder is inverted, positioned through the center of the carriages, and a steel collar that's welded to the cylinder casing will contact the lifting plate on the carriage. The cylinders are driven by a hydraulic pump capable of providing 3,000 psi.

Please read the Safety Procedures and operation instructions in this manual before operating the lift. Proper installation is very important. To minimize the chance of making an error in installation, we recommend that this equipment be installed by a professional equipment installer that is well versed in these types of lifts. Check with building owner and/or architect's building plans when applicable. The lift should be located on a level floor with 6" 3000 psi concrete sufficiently cured, for at least 30 days.

This is a vehicle lift installation / operation manual and no attempt is made or implied herein to instruct the user in lifting methods particular to an individual application. Rather, the contents of this manual are intended as a basis for operation and maintenance of the unit as it stands alone or as it is intended and anticipated to be used in conjunction with other equipment.

Proper application of the equipment described herein is limited to the parameters detailed in the specifications and the uses set forth in the descriptive passages. Any other proposed application of this equipment should be documented and submitted in writing to the factory for examination. The user assumes full responsibility for any equipment damage, personal injury, or alteration of the equipment described in this manual or any subsequent damages.



1. Extending post
2. Hydraulic power unit
3. Post
4. Control unit
5. Overhead crossbeam
6. Up pulley assembly
7. Hydraulic cylinder
8. Carriage

3-UNPACKING & SETUP

Only skilled personnel who are familiar with the lift and this manual shall be allowed to carry out, lifting, handling, transport and unpacking operations.

3.1 DELIVERY AND CHECK OF PACKAGES

When the lift is delivered, carefully unpack the lift making sure all the parts have been included. Check for possible damages due to transport and storage; verify that what is specified in the confirmation of order is included. In case of damage in transit, the customer must immediately inform the carrier of the problem.

Remove the lift and all parts from delivery pallet and place on a clean, solid, flat surface. Packages must be opened paying attention not to cause damage to people (keep a safe distance when opening straps) and parts of the lift (be careful the objects do not drop from the package when opening.)

3.2 LIFTING AND HANDLING

When loading/unloading or transporting the equipment to the site, be sure to use suitable loading (e.g. cranes, trucks) and hoisting means. Be sure to hoist and transport the components securely so that they cannot drop, taking into consideration the package's size, weight, center of gravity, and its fragile parts.



LIFT AND HANDLE ONLY ONE PACKAGE AT A TIME

3.3 PREPARATION

Professional installation is required. The following tools and equipment are needed:

1. ISO-32 or AW-32 hydraulic oil (2.5 Gallons)
2. Chalk line and Tape Measure
3. Rotary Hammer Drill with 3/4" Drill Bit. Core Drill Rebar Cutter recommended
4. 4' Level
5. Sockets and Open Wrench set, metric & standard (1-1/8" for 3/4" Anchors)
6. Pliers
7. Torque Wrench
8. Metric allen wrench set

4 SPECIFICATIONS

SPECIFICATIONS	SYMMETRICAL CONFIGURATION	ASYMMETRICAL CONFIGURATION
Outside Of Baseplates - Width	154-7/8"	161-1/2"
Inside of Columns - Width	131-3/4"	126"
Overall Width w/Motor	160-3/16"	161-1/2"
Drive-Thru	119"	113-3/8"
Lifting Height	4-5/16" to 74-13/16"	
Overall Height	153-9/16" or 175-1/4"	
Lifting Capacity	12,000 lb	
Shipping Weight	2,190 lb	
Power Unit	220V-60Hz-1Ph-2.2kW	

Due to minor variances in the manufacturing process, dimensions in this manual may vary slightly from the finished product.

5-FLOOR REQUIREMENTS

5.1 SELECTING THE SITE AREA

1. Make sure that adequate space and height is available.
2. Check for ceiling clearance (lifting height plus vehicle height).
3. Check for clearance in front and rear of vehicle on lift.
4. Check for overhead garage door clearance.

5.2 FLOOR REQUIREMENTS

Do not use the lift on any asphalt surface. Make sure the lift is used on a dry, oil/grease free, flat level CONCRETE surface capable of supporting the weight of the lift, the vehicle being lifted, and any additional tools and equipment. The concrete floor surface should have a minimum thickness of 6". The concrete must have a minimum strength of 3,000 PSI, and should be aged at least 30 days prior to use. Do not use the lift on concrete expansion seams or on cracked, defective concrete.



WARNING: SPECIFICATIONS OF CONCRETE MUST BE ADHERED TO. FAILURE TO DO SO COULD CAUSE LIFT FAILURE RESULTING IN PERSONAL INJURY OR DEATH. THE FLOOR SHOULD BE A REINFORCED CONCRETE SLAB NOT LESS THAN 6" THICK WITH THE COMPRESSIVE STRENGTH OF THE CONCRETE NO LESS THAN 3,000 PSI.





DANGER: FOR CORRECT INSTALLATION OF THE LIFT, THE FLOOR MUST BE FLAT AND LEVEL. CHECK WITH STRAIGHT EDGE AND LEVEL. IF A FLOOR IS OF QUESTIONABLE SLOPE, CONSIDER A SURVEY OF THE SITE AND/OR THE POSSIBILITY OF POURING A NEW LEVEL CONCRETE SLAB.



IMPORTANT: NEW CONCRETE MUST BE ADEQUATELY CURED AT LEAST 30 DAYS MINIMUM. NO LIABILITY FOR ANY DAMAGES WILL BE ACCEPTED SHOULD YOU INSTALL THE LIFT ON AN UNSUITABLE FLOOR.

5.3 IMPORTANT CONCRETE AND ANCHORING INFORMATION

1. Concrete shall have compression strength of at least 3,000 PSI and a minimum thickness of 6". Measure the length of the supplied anchor bolts in order to achieve a minimum anchor embedment of 3-1/4". If the top of the anchor exceeds 2" above the floor grade, you DO NOT have enough embedment.
2. Before drilling 3/4" dia. Holes in concrete floor using holes in column base plate as guide, make sure the hole distance from the edge is not less than 6". Hole to hole spacing should not be less than 6 1/2 in any direction. Concrete thickness should be a minimum of 6".
3.  **DANGER: DO NOT** Install on asphalt or other similar unstable surface. Columns are supported only by anchoring in floor.
4. Shim each column base until each column is plumb. If one column has to be elevated to match the plane of the other column, full size base shim plates should be used. Torque anchors to 85 ft-lbs. Shim thickness MUST NOT exceed 1/2". Adjust the column extensions plumb.
5. If anchors do not tighten to 85 ft-lbs. installation torque, replace concrete under each column base with a 4' x 4' x 12" thick 3,000 PSI minimum concrete pad keyed under and flush with the top of existing floor. Let concrete cure at least 30 days before installing lifts and anchors.




**DO NOT USE AN IMPACT
WRENCH TO TIGHTEN
ANCHORS!**

5.4 ANCHORING TIP SHEET


1. Use a concrete hammer drill with a carbide tip, solid drill bit the same diameter as the anchor, 3/4". (.775 to .787 inches diameter). **Do not use excessively worn bits or bits which have been incorrectly sharpened.**
2. Keep the drill perpendicular to the concrete while drilling.
3. Let the drill do the work. Do not apply excessive pressure. Lift the drill up and down occasionally to remove residue to reduce binding.
4. Drill the hole for anchor bolt completely through the concrete. If an error is made during the installation of these anchors, this will allow for the anchor bolt to be driven down into the ground, so that a new anchor may be installed in place (fig.1).
5. **Be sure to clean all dust from hole.** (fig. 2).
6. Place a flat washer and hex nut over threaded end of anchor, leaving approximately 1/4 inch of thread exposed above the nut (fig. 3). Carefully tap anchor into the concrete until nut and flat washer are against base plate. Be sure to only tap the top of the anchor and not the nut. This could cause damage to the threads of the anchor.
7. Tighten the nut (fig. 4) to **85 ft-lbs** of torque.

6-INSTALLATION INSTRUCTIONS

PLEASE NOTE THAT ALL DIMENSIONS GIVEN ARE FOR REFERENCE ONLY. FINAL DIMENSIONS MAY VARY SLIGHTLY. LIFT COLUMNS MUST BE PLUMB AND SQUARE REGARDLESS OF FINAL DIMENSIONS.

PLEASE THOROUGHLY READ THESE INSTRUCTIONS BEFORE BEGINNING INSTALLATION OR OPERATION OF THE LIFT.


1. First, decide on the type of configuration for column height. Depending on the ceiling height of work shop, the total height configuration can either be 153 9/16" or 175 1/4". There are four pairs of holes reserved on extending piece. On condition that the ceiling of your workshop is higher than 175 1/4", it is preferred to fix the extending piece with the main column using the pairs of holes P3 and P4, and tighten the support plate (Pos.7) accordingly. If the ceiling is lower than 175 1/4", tighten the extending piece directly with main column using the pairs of holes P1 and P2. For this setting you will not be using the supporting plate (Pos.7).



1. Hex head full swivel screw M14*40
2. Flat washer M 14
3. Spring washer M14
4. Hex nut M14
5. Extending piece
6. Main post
7. Support plate (optional, only usable for the total height of 4452mm)

2. Assemble the overhead crossbeam and fix the roof protective rod. First, assemble beam 1 with beam 2 and tighten them using the correct pairs of holes indicated in the following scheme. This setting will be on the beams widest setting as indicated with the arrows below. Then, make one end of the roof protective rod (Pos.7) go through the hole of the holder attached under the beam and fix the other end of the rod with the beam using hex socket cylinder head screw M6x35 (Pos.2).


CAUTION! IT IS IMPORTANT TO CHECK AND ASSURE THE ENTIRE BEAM IS STRAIGHTLY CONNECTED WITH NO TWISTING. TO GET RID OF THE TWISTING, YOU CAN ADJUST THE SCREWS (POS.3) THAT TIGHTEN BEAM 1 AND BEAM 2.




- | |
|---|
| 1. Hex locking nut M6 |
| 2. Hex socket cylinder head screw M6x35 |
| 3. Hex head full swivel screw M14x30 |
| 4. Flat washer M14 |
| 5. Spring washer M14 |
| 6. Hex nut M6 |
| 7. Roof protective rod |

3. Decide the mounting position that works best for your application and erect the posts. (See Annex 1, Floor plan)
 - A. Ascertain the type of configuration.
 - B. Depending on the type of vehicles to be lifted, the column configuration can either be asymmetrical or symmetrical.
 - C. Identify on which side of the lift the power unit column will be mounted.
 - D. Draw an outline of the base plate on the installation ground with chalk and ascertain the position for the two posts. (Refer to the fig. in step 5)
 - E. Refer to 3.4 dimensions of the lift, make the posts face to each other and use proper means to erect the posts.

SYMMETRIC COLUMN CONFIGURATION



ASYMMETRIC COLUMN CONFIGURATION



ASYMMETRIC COLUMN CONFIGURATION CONTINUED



Align the two base plates, making the marking points C1, C2, C3 and C4 are in the same straight line.



4. Drill the mounting holes. Remove the drilling dust from the hole.
5. Use a level to check the vertical alignment of the posts. Place shims under the base plates when it necessary to ensure the column is plumb.

Caution: Don't add more than 1 shim under one anchor position of the base plate, otherwise there could be risks of slanting due to uneven load transfer to the foundation.

6. Tighten the nuts. Torque: 85 ft-lbs.



Anchor Bolt	A1 (Concrete thickness)
3/4" x 200	6" @ 3,000 PSI




7. Assemble the pulleys correctly and install the crossbeam onto the two posts.

- A. Firstly, ascertain the type of configuration. Ascertain and mark the correct holes on the crossbeam and connecting part before installation. The pulleys and crossbeam shall be installed using the correct holes indicated in the following schemes.

Caution! The pulleys and connecting plates shall be installed using the correct mounting holes specified in the following instructions. Otherwise there could be risks of interference.

SYMMETRIC CONFIGURATION

- B. There are 2 pairs of holes reserved on each end of the beam for installing the pulleys.
- C. For Symmetrical column configuration, the two pairs of pulley shall be installed using holes P1, P2, P7, and P8 on the crossbeam.
- D. Otherwise there could be risks of interference between steel rope and connecting plate.



ASYMMETRIC CONFIGURATION

- A. LAYOUT 1 , the two pairs of pulley shall be installed using holes P2, P3, P5, P8 on the crossbeam.





LAYOUT 1

column base 1
column with control and power unit

Drive-on direction

column base 2


Vehicle Head



ASYMMETRIC CONFIGURATION


- A. LAYOUT 2 , the two pairs of pulley shall be installed using holes P1, P4, P6, P7 on the crossbeam.

LAYOUT 2



8. Fix the two connecting plates onto both ends of the crossbeam assembly using the correct mounting holes respectively instructed in the above figures.

9. Connect the beam with the two posts.





1. Hex head full swivel screw M14x30
2. Flat washer M14
3. Spring washer M14
4. Hex nut M14

10. Assemble the mechanical locking unit.

locking device on power side post

locking device on the secondary post




1. Circlip
2. Washer
3. Spring 1
4. Spring 2
5. Shaft
6. Hex socket flat head screw M8*65

7. Hook
8. Nylon spacer
9. Release plate
10. Rope protective winder
11. Rope fastener


11. Route and fix the safety release cable for mechanical locking assembly.

- A. There are 2 pairs of holes reserved on the top side of column and 4 pairs of holes reserved on the holder (Pos.2) assembled with cable-guiding pulley.
- B. Aligned the bottom pair of holes of the holder with the pair of holes marked with "✓" in following figure and fasten the holder using the screws and nuts (Pos.1 and Pos.3).


CAUTION! The holder (Pos.2) shall be positioned along the inside surface of the column.
CAUTION! Install the other holder symmetrically at the same position of the other column.
CAUTION! Don't install the holder using the other pair of holes marked with "x" .



1. Hex socket cylinder head screw M8X25
2. Holder for guiding pulley
3. Hex locking nut M8
4. Release steel rope




- C. Route the release rope properly along the pulleys, making one of its end go across the top beam and reach the other column.
- D. Tighten both ends of the rope onto the fittings reserved on both locking units.



12. Install the switch.


- A. Install the switch bracket (# 4) onto the column and mount the switch (# 1) onto the bracket.
- B. The position of the switch should be mounted to its lowest setting on the bracket. Making it so that the release handle (# 6) when pulled down fully contacts the switch fully activating it.



1. Switch
2. Hex socket cylinder head screw M4x35
3. Hex socket cylinder head screw M6x10
4. Holder for the switch
5. Self-locking nut M4
6. Release handle

13. Route and connect the equalizing cables.


- A. Ascertain the height configuration.
- B. Before attempting to route the ropes, raise the lifting carriage at both sides to the first latching position making sure that the mechanical safety locking units in each post are fully engaged.
- C. The following scheme indicates rope tightening positions for configuration with a total height of (153 9/16").
- D. For higher configuration with a total height of (175 1/4"), tighten the two ends of ROPE 2 from P1 to P2 and from P3 to P4.
- E. Tighten the two ends of ROPE 1 from P5 to P1 and from P4 to P6.



- G. Adjust and make the ropes at both sides be under the same tension which could be judged by the sound emitted during lifting process.
- H. Grease with No.1 lithium grease

14. Install the power unit.


A. Mount and tighten the power unit onto the extending post.



- 1. Hex head flange screw M8x30
- 2. Anti-vibration pad
- 3. Hex flange nut M8
- 4. Hydraulic power unit
- 5. Extending post
- 6. Main post

15. Connect the hydraulic hoses

- A. It must be taken adequate care that all connectors shall be tightened against leakage.
- B. Don't let any solid substance go into the hydraulic line. Severe leakage will occur if the hose connectors are not tightened.
- C. The following diagram shows the way of connection for the total height configuration of (175 1/4").
- D. Connect hose 3 directly with the three-way connector (Pos.5) for lower height configuration of (153 9/16").
- E. Torque: 20 ft-lbs




1. Rubber oil hose 1, L=16 9/16"
2. Rubber oil hose 2, L=42 1/2" (optional, only usable for a total height of 175 1/4")
3. Rubber oil hose 3, L=315 3/4"
4. Rubber oil hose 4, L=119 5/16"
5. Three way connector
6. Straight connector (optional, only usable for a total height of 175 1/4")
7. Oil cylinder

16. Make the electrical connection.

- **ONLY qualified electricians are permitted to do the electrical connection.**
- Read the name plate and check that the supply voltage is adapted to the voltage of the lift.
- Read electrical connection diagram for reference before doing the connection.


Caution: All electrical wires shall be properly secured against interference with the cables.

A. Mount the control box onto the power side post.




- | |
|---|
| 1. Control box
2. Hex socket cylinder head screw M6x10
3. Power side post |
|---|

- B. Fix the max-height limit switch onto the inside surface of the power side post.
- C. Connect the wires of the switch with the corresponding terminals reserved in the control box.



- | |
|---|
| 1. Cross socket flat head screw M5x10
2. Max height limit switch |
|---|

- D. Fix roof-protection limit switch onto the overhead crossbeam and connect its wires with the corresponding terminals reserved in the control box.



1. Roof protection limit switch
2. Cross socket flat head screw M4x25

- E. Refer to the wire connection schemes and connect wires to the corresponding terminals in the control box.


- F. Connect power supply cable with the terminals reserved in the control box.

18. Install lifting arms.

- The arm pin shafts (No. 2) must be greased at the installation.

- A. Install the lifting arms onto the carriages and ensure the arm lock could engage and release effectively.

Attention: Install lifting arms ONLY after the complete assembly has been erected and anchored.



1. Carriage
2. Pin shaft
3. Swing arm
4. Pulling rod
5. Arm lock

17. Fill with ISO-32 or AW-32 hydraulic oil.

ONLY CLEAN AND FRESH OIL ONLY

- Change the oil 6 months after initial use and once per year thereafter.

18. Trial running

- The purpose for trial run is to check whether the lift is ready for safe use.
- The user needs to get familiar with lift controls through raising and lowering the lift a few cycles before using it to lift vehicles.

Bleeding the hydraulic system

- A. To vent the air remaining in the oil cylinder. Locate the screw at the top of the cylinder. Loosen the screw but don't remove the nut on top of the oil cylinder and slightly press the UP button until oil comes out. Screw the nut tight thereafter.



Vent air remained in the cylinder

- B. After bleeding, fluid level in power unit reservoir may be down. Add more fluid if necessary to raise lift to full height. It is only necessary to add fluid to raise lift to full height.

Check the mechanical safety locking system.

- A. Check if the mechanical locks can be engaged and released in the lifting and lowering process.
- B. Adjust the tension of the release wire when or if necessary.

Check the synchronization of lifting carriages.

- A. Adjust the nuts on the equalizing cables at both sides so that they have the same amount of tension. This can be checked by squeezing the cables together with your hand.
- B. This could be judged by the sound emitted by the safety locking unit during lifting process.


Check the hydraulic lines.

- A. Raise and lower for several complete cycles and inspect if the hose connectors, cylinders and valves are well tightened without leakage.
- B. Check the speed for rising and lowering, ensuring that the maximum permitted speeds are not exceeded.


If the lift doesn't raise, the motor may turn in the wrong direction. In such event, interchange wires U, V in the connection box.

19. Attach the two protective covers.

- A. Fix the covers (Pos.1, Pos.4) onto the posts



20. Attach door-opening protection pads #2, plastic protective cover #4 and pick up pads #5.



7-OPERATION INSTRUCTIONS

⚠ WARNING: LIFT OPERATION BY TRAINED AUTHORIZED PERSONNEL OVER 18 YEARS ONLY. APPLY THE PARKING BRAKE AFTER POSITIONING THE VEHICLE ON THE LIFT. DO NOT ALLOW ANYONE TO STAY IN LIFT AREA DURING RAISING AND LOWERING CYCLES. CLOSELY WATCH THE VEHICLE AND THE LIFT DURING RAISING AND LOWERING CYCLES. OBSERVE THE RATED LOAD CAPACITY AND LOAD DISTRIBUTION. DO NOT ALLOW ANYONE TO CLIMB ON LIFT OR STAY INSIDE VEHICLE. AFTER RAISING THE VEHICLE FRAME 6”, STOP AND CHECK ADAPTERS FOR SECURE CONTACT. PERFORM BUMPER TEST. MAKE SURE THE VEHICLE DOORS ARE CLOSED DURING RAISING AND LOWERING CYCLES.

7.1 DEFECTS / MALFUNCTIONS

⚠ WARNING: IN CASE OF DEFECTS OR MALFUNCTIONS SUCH AS JERKY LIFT MOVEMENT OR DEFORMATION OF THE SUPERSTRUCTURE, SUPPORT OR LOWER THE LIFT IMMEDIATELY. CONTACT QUALIFIED SERVICE PERSONNEL.

7.2 CONTROLS


7.2.1 UP CONTROL

Once the UP button is pressed, the lift moves up until the button is released or the limit stop is reached.

7.2.2 SAFETY LOCK CONTROL

The safety lock mechanism will “Trip Over” as the lift raises and drop into each safety latch stop. To lock the lift, you must press the lowering button (SB2) on the control panel to relieve the hydraulic pressure and let the safety locks engage into a level locked position.

POS.	Descriptions	Function
1	Handle	Release the mechanical lock and control the descending movement.
QS	Power switch	Turn on or off the power supply.
HL	Power indicator	Indicate if power is connected or not.
SB1	UP button	Control the rising movement.
SB2	Down / Safety lock	Engage the mechanical safety lock.



⚠ WARNING: PAY CLOSE ATTENTION WHEN SETTING THE LOCKS. THE LOCKS MUST BE A LEVEL MATCH SET IN ORDER TO AVOID A VEHICLE TILT.

⚠ WARNING: ALWAYS LOCK THE LIFT BEFORE GOING UNDER THE VEHICLE. NEVER ALLOW ANYONE TO GO UNDER THE LIFT WHEN RAISING OR LOWERING.



NOTE: IT IS NORMAL FOR AN EMPTY LIFT TO LOWER SLOWLY - IT MAY BE NECESSARY TO ADD WEIGHT.

7.2.3 LOWERING CONTROL

Press the power button to raise the carriages high enough up off the locks so that they can be disengaged. Pull down on the lock release lever located on the power unit column to manually disengage both locks.



WARNING: BE SURE THAT BOTH LOCKS HAVE FULLY DISENGAGED BEFORE LOWERING.

7.3 OPERATION




WARNING: FAILURE TO OPERATE THE LIFT ACCORDING TO THIS MANUAL MAY CAUSE DAMAGE TO THE LIFT, PROPERTY DAMAGE AND/OR PERSONAL INJURY.

21. Before driving a vehicle onto the lift make sure the lift is fully lowered and position the lift arms outward. Do not hit or run over the lifting arms, as this could damage the vehicle and/or lift. Make sure the lift is fully lowered before moving the vehicle over the lift.
NOTE: It is recommended to swing both arms outward pointing toward the front of the lift prior to loading a vehicle onto the 12KMSC.
22. Drive the vehicle over the lift while keeping the vehicle parallel with the lift and aligning the center of gravity of the vehicle with the center of the lift. **NOTE:** The “Center of Gravity” (COG) of the vehicle is the balance point at which there is equal weight in front of and behind the COG, and equal weight on both sides of the COG. The COG is not necessarily the dimensional center of the vehicle, but is often slightly toward the engine from the dimensional center of the vehicle.
23. Turn off the vehicle’s engine and engage the parking brake of the vehicle.
24. Read the vehicles owner’s manual to identify the recommended vehicle lifting points.
25. Prepare the work area according to this manual. Move the lifting arms inward, and position the rubber pads to contact with the vehicle manufacturer’s recommended lifting points.




IMPORTANT: PLACE THE FOUR RUBBER PADS UNDER EDGE OF VEHICLE AT THE FOUR JACK POINTS.

26. Once the lifting arms have been positioned under the vehicle lifting points, operate the power switch to make contact and lift the vehicle slightly. Test to make sure the vehicle is well balanced and the contact between the rubber pads and vehicle lifting points are secure by performing the “BUMPER TEST.” (pg. 2) Then proceed to lift the vehicle to the desired height.

27.  **WARNING:** Do not lift the vehicle if you cannot establish secure and level lifting points. Do not use sub-standard shims or other devices in place of approved and recommended rubber pad adapters. Never use the lift without the rubber pads in place on each plate and in contact with the lifting points of a vehicle.
28. Press up button and raise vehicle to desired height. Do not go under vehicle until load rests on level safety locks.
29. While lifting the vehicle a clicking sound should be noticeable which indicates the safety mechanism is operating. If this sound is not heard, immediately cease using the lift and call an authorized service agent.
30. When lift reaches maximum height, a limit switch will come into operation and stop the lift. When lift has stopped, press and hold the lowering handle until load rests on level safety locks.
31. Once the repair work to the vehicle is complete, make sure to remove all tools, safety jack stands, and materials from under the vehicle and lift. Also, make sure the work area is clear and it is safe to lower the vehicle.
32. Lower vehicle by pressing the Up button to disengage the safety locks. Pull down on the safety release lever to release the safety locks then press the lowering handle until the lift is completely lowered.
33. Move the lifting arms outward, out of the path of the vehicle. Clear all bystanders, and any objects from work area and direction of vehicle.
34. Disengage the vehicle parking brake. Start the vehicle's engine, and drive the vehicle off the lift slowly and carefully.

 **WARNING: THE OPERATOR MUST BE TRAINED AND AUTHORIZED TO OPERATE THE LIFT.**

 **WARNING: DO NOT GO UNDER VEHICLE UNDER ANY CIRCUMSTANCES WHILE VEHICLE IS BEING RAISED OR LOWERED.**

 **WARNING: LOAD MUST BE EVENLY DISTRIBUTED BETWEEN BOTH LIFTING PLATFORMS. IF LOAD IS UNBALANCED, REPOSITION VEHICLE. DO NOT LOWER ON TO LOCKS AT DIFFERENT HEIGHTS.**

8-MAINTENANCE

 **WARNING: DISCONNECT THE POWER BEFORE SERVICING THE LIFT.**

 **IMPORTANT: THE MAINTENANCE INTERVALS INDICATED BELOW APPLY TO AVERAGE WORKSHOP USE. THE LIFT SHOULD BE INSPECTED MORE FREQUENTLY FOR SEVERE USE APPLICATIONS.**

8.1 MAINTENANCE SCHEDULE

It is important to keep the lift clean, dry, and well maintained by establishing a periodic preventive maintenance program to ensure trouble-free operation and long service life.

8.1.1 DAILY

1. Check safety locking mechanism is functioning correctly.
2. Check safety lock audibly and visually while in operation.
3. Check safety latches for free movement and full engagement with rack.
4. Inspect the condition of rubber lifting pads and replace as necessary if worn or torn.
5. Check hydraulic connections, and hoses for leakage.
6. Check chain connections - Bends, cracks - and looseness.
7. Check for frayed cables in both raised and lowered positions.
8. Check snap rings at all rollers and sheaves.
9. Check bolts, nuts, and screws and tighten.
10. Check wiring & switches for damage.
11. Keep base plate free of dirt, grease or any other corrosive substances.
12. Check floor for stress cracks near anchor bolts.
13. Check swing arm restraints.

8.1.2 WEEKLY

1. Check anchor bolts torque to 85 ft-lbs for the 3/4" anchor bolts.
NOTE: DO NOT USE IMPACT WRENCH.
2. Check floor for stress cracks near anchor bolts.
3. Check hydraulic oil level.
4. Check and tighten bolts and nuts, and screws.
5. Check cylinder pulley assembly for free movement or excessive wear on cylinder yoke or pulley pin.
6. Check cable pulley for free movement and excessive wear.

8.1.3 MONTHLY

1. Check safety mechanism operation.
2. Check condition of shafts, shaft locks and bushings.
3. Check overall cleanliness.

8.1.4 BIMONTHLY

1. Check condition of extensions and lubricate.
2. Check oil leaks from cylinders.
3. Check oil leaks at pipe joints.

8.1.5 YEARLY

Service and safety inspection on the lift must be performed by a competent person. This inspection must be recorded. If the 12 month service and safety inspection is not performed, the warranty is null and void.

1. Lubricate chain, if equipped
2. Grease rub blocks and column surface contacting rub blocks.
3. Change the hydraulic fluid. A good maintenance program makes it mandatory to keep hydraulic fluid clean. Operating temperature, type of service, contamination levels, filtration, and chemical composition of fluid should be considered. If operating in harsh or dusty conditions, a shorter interval may be required.

THE FOLLOWING ITEMS SHOULD ONLY BE PERFORMED BY A TRAINED MAINTENANCE EXPERT.

- Replace hydraulic hoses.
- Replace chains and rollers.
- Replace cables and sheaves.
- Replace or rebuild air and hydraulic cylinders as required.
- Replace or rebuild pumps / motors as required.
- Check hydraulic and air cylinder rod and rod end (threads) for deformation or damage.
- Check cylinder mount for looseness and damage.

Relocating or changing components may cause problems. Each component in the system must be compatible; an undersized or restricted line will cause a drop in pressure. All valve, pump, and hose connections should be sealed and/or capped until just prior to use. Air hoses can be used to clean fittings and other components. However, the air supply must be filtered and dry to prevent contamination. Most important - **CLEANLINESS** - contamination is the most frequent cause of malfunction or failure of hydraulic equipment.

8.1.6 EVERY OTHER YEAR

Hydraulic oil should be replaced.



IMPORTANT: AFTER CLEANING WORKSHOP FLOOR OR LIFT, TO MAINTAIN HOIST EFFICIENCY WE ADVISE TO LUBRICATE LIFTING ARM LOCKING MECHANISM, AND SAFETY LOCKING MECHANISM. CHECK SAFETY LOCKING MECHANISM IS FUNCTIONING CORRECTLY.

8.2 MAINTENANCE BY OPERATOR

All moving parts have been lubricated at the factory and should be re-lubricated before the first use and at least once every six months to prevent damage.

8.2.1 HYDRAULIC SYSTEM

1. Check the fluid level with the lift fully lowered and add fluid as required. Use premium quality ISO-32 or AW-32 hydraulic oil.
2. Visually check all hydraulic hoses and connections for tightness before each use to ensure proper working condition.
3. Lightly oil the cylinder rods at least once every six months or when they become dry.

8.2.2 GREASING POINTS

SLIDE TRACKS:

- The carriage assembly slide tracks should be greased every six months (or more frequently in case of noise generation).
- Slightly grease the slide tracks over their whole length using a brush.

8.2.3 OPERATION AND WEAR CHECKS

1. Examine lift for structural cracks, bends, or other signs of damage prior to each use. Do not use this product if worn or damaged.
2. Check that the safety locking mechanism is functioning correctly.
3. Check that the safety lock is audibly and visibly operating correctly.
4. Check the floor for stress cracks near the anchor bolts.

8.2.4 LIFT STABILITY

1. Every six months check the nuts of all bolts for correct installation torque.
2. Retighten them as required. **NOTE: DO NOT USE AN IMPACT WRENCH.**

8.3 CLEANING



DANGER: DO NOT USE HIGH PRESSURE / STEAM JET CLEANERS OR CAUSTIC CLEANING AGENTS.

1. Periodically wash off aggressive substances and treat the lift with oil or wax spray.
2. Repair the damage to the paintwork immediately to prevent corrosion.

9-TROUBLESHOOTING

- 1. Motor does not run:**
 - A. Breaker or fuse blown.
 - B. Motor thermal overload tripped. Wait for overload to cool.
 - C. Faulty wiring connections.....Call electrician for service.
 - D. Defective up button.....Call electrician for service.
- 2. Motor runs but will not raise:**
 - A. A piece of debris could be stuck in the lowering valve. Push handle down and push the up button at the same time. Hold for 10-15 seconds. This should flush the system.
 - B. Check the clearance between the plunger valve of the lowering handle. There should be 1/16”.
 - C. Remove the check valve cover and clean ball and seat.
 - D. Oil level too low. Oil level should be just under the vent cap port when the lift is in the lowered position.
- 3. Oil blows out breather of power unit:**
 - A. Oil reservoir overfilled.
 - B. Lift lowered too quickly while under a heavy load.
- 4. Motor hums and will not run:**
 - A. Impeller fan cover is dented. Take off and straighten.
 - B. Faulty wiring.....Call electrician.
 - C. Bad capacitor.....Call electrician.
 - D. Low voltage.....Call electrician.
 - E. Lift overloaded.....Reduce weight.
- 5. Lift jerks going up and down: Air in hydraulic system. Raise lift all the way to top and return to floor; Repeat 4-6 times. Do not let this overheat power unit.**
- 6. Oil leaks:**
 - A. Check the power unit: If the power unit leaks hydraulic oil around the tank-mounting flange, check the oil level in the tank. The level should be two inches below the flange of the tank. Check with a screwdriver.
 - B. Check the rod end of the cylinder: If the rod seal of the cylinder is out, rebuild or replace the cylinder.
 - C. Breather end of the cylinder: If the piston seal of the cylinder is out, rebuild or replace the cylinder.
- 7. Lift makes excessive noise:**
 - A. Leg of the lift is dry and requires grease.
 - B. Cylinder pulley assembly or cable pulley assembly is not moving freely.
 - C. May have excessive wear on pins or cylinder yoke.

10-OWNER/EMPLOYER RESPONSIBILITIES

The owner/employer:

Shall establish procedures to periodically maintain, inspect and care for the lift in accordance with the manufactures recommended procedures to ensure it's continued safe operations.


Shall provide necessary lockout / tag outs of energy sources per ANSI Z244.1 - 1982 before beginning any lift repairs. Shall not modify the lift in any manner without prior written consent of the manufacturer.

Shall display this manual or copy supplied with the lift in a conspicuous, dry location in the lift area convenient to the operator.

Shall insure that lift operators are instructed in the safe proper use and operation of the lift using the manufacturer's instructions outlined within this manual supplied with the lift.


11-DIAGRAMS (FIG. 1-10)

FIG. 1 - POWER UNIT




No.	Code	Description	QTY
1	320204309	Motor - 208-240V,50/60Hz,2.2KW	1
2	330404006	Coupling - 48mm(YBZ-F2.1D4H1/1-03)	1
3	207103025	Composite washer - 13_7X20X1_5	2
4	202109145	Bolt - YBZ-E3D4H1/10-02	4
5	330302006	Non-return valve - DF08-01-00	1
6	330311005	Solenoid valve spool - 24DC(LSV-08-2NCP-M-2H)	1
7	330308032	Plug - DIN43650-DC	1
8	330308046	Coil - ECHS24DC-UL	1
9	203204102	Nut - FHLM-1/2-20UNF	1
10	202109072	Hex socket cylinder head screw - M8x85-GB70_1	2
11	202109144	Bolt - M5x18	4
12	330502015	Breather - YBZ-BT-G3/4-C	1
13	330405069	Oil tank - TK-120-10L-L-K	1
14	330313001	Restrictive valve for descending - BL-12.5	1
15	330105066	Hydraulic block - LBZ-T2KK-4B	1
16	330304014	Relief valve - LHRV-08-42	1
17	330600005	Pipe joint - YBZ-F2.51/0000T1-02	1
18	330301003	Cushion valve - HCF-Z1/4	1
19	207101098	O seal ring - 109*5.3	1
20	330201006	Gear pump - CBK-F225/CBK-2.5F	1
21	330401013	Oil sucking pipe - YBZ-SJYG350	1
22	330402006	Oil returning pipe - YBZ-E2D311/1-09	1
23	330403003	Suction filter - YBZ-E2D311/1-10	1

FIG. 2 - HYDRAULICS




No.	Code	Description	QTY
1	622034431	Power unit - 220V-60Hz-1Ph-2.2kW	1
2	207103025	Composite washer - 13_7X20X1_5	5
3	310101008	Shift connector - M14*1.5-G1/4 inside cone	1
4	624008261	Rubber oil hose 1 - $\Phi 8$,L=420mm	1
5	615006003	Three way connector - 6214E-A4-B4	1
6	624002161	Rubber oil hose 3 - L=8020mm	1
6.1	624008256	Rubber oil hose 2(only usable for a total height of 4452mm) - L=1080mm	1
6.2	410210191	Straight connector(only usable for a total height of 4452mm) - 6603B-A9-B8	1
7	624008257	Rubber oil hose 4 - L=3030mm	1
8	615015003	Composite connector - 6255E-A7-B7	2
9	625000013	Oil cylinder - YG5060-38-1800	2

FIG. 3 - HYDRAULICS




No.	Code	Description	QTY
1		Power unit	1
2	624008261	Rubber oil hose 1 - $\Phi 8$,L=420mm	1
3	624008257	Rubber oil hose 4 - L=3030mm	1
4	615015003	Composite connector - 6255E-A7-B7	2
5	207103025	Composite washer - 13_7X20X1_5	4
6	615006003	Three way connector - 6214E-A4-B4	1
7	624008256	Rubber oil hose 2(only usable for a total height of 4452mm) - L=1080mm	1
8	625000013	Cylinder - YG5060-38-1800	2
9	410210191	Straight connector(only usable for a total height of 4452mm) - 6603B-A9-B8	1
10	624002161	Rubber oil hose 3 - L=8020mm	1

FIG. 4 - SAFETY CABLE & CROSSBEAM




No.	Code	Description	QTY
1	410912431	Release rope - L=9400	1
1	614901940	Crossbeam(outside) - C12V3-A21-B1	1
2	201102035	Hex head full swivel screw - M14X30-GB5783	9
3	204101008	Flat washer - D14-GB95	9
4	204201007	Spring washer - D14-GB93	9
5	203101008	Hex nut - M14-GB6170	9
6	614901941	Crossbeam(inside) - C12V3-A21-B2	1
7	202111004	Hex socket flat head screw - M8X12-GB70_3	2
8	612056001	Upside pulley shaft - C12-A1-B3	4
9	205101101	Bearing - 3520-SF-1X	4
10	410902109	Pulley - C9Z-A1-B2	4
11	410160023	Rod - 6215E-A10-B3	1
12	420060010	Black foam tube - 6214E-A21-B3	1
13	202109024	Hex socket cylinder head screw - M6X35-GB70_1	1
14	203103005	Hex locking nut - M6-GB889_1	1
15	614901942	Connecting plate - C12V3-A21-B3	2

FIG. 5 - SAFETY LOCKS






No.	Code	Description	QTY
1	410902013	Spring - C9Z-A1-B10	2
2	410902014	Spring - C9Z-A1-B11	2
3	410010031	Washer - 6254E-A1-B3	4
4	204301009	Circlip - D25-GB894_2	4
5	410902031	Shaft - C9Z-A1-B6	2
6	202111033	Hex socket flat head screw - M8x65-GB70_3	2
7	202109152	Hex socket cylinder head screw - M4X5-GB70_1	2
8	203101005	Hex nut - M8-GB6170	4
9	615068400	Handle - C9Z-A1-B12	1
10	420680066	Nylon spacer - 25X41X25	2
11	206102013	Post pin - D6X40-GB879	2
12	615068399B	Hook assembly - C9Z-A1-B4-1	2
13	612901742	Release bracket - C9Z-A1-B5-V1	1
14	202109017	Hex socket cylinder head screw - M6X8-GB70_1	8
15	614006012B	Guiding bracket for lock release device - 6214DS-A9	1
16	420080030	Pulley II - 6214DS-A7	5
17	204301001	Circlip - D10-GB894_1	2
18	410540530	Release plate - C12-A1-B5-C1	1
19	208101037	Rope fastener - M3-1	1
20	410911492	Holder for the switch - C9ZV3-A1-B18	1
21	202109018	Hex socket cylinder head screw - M6X10-GB70_1	2
22	430020260	Rope protective winder	1

FIG. 6 - EXPLODED PARTS




No.	Code	Description	QTY
1	420680175	Protective cover 1 - C9Z-A19-B1	1
2	202109017	Hex socket cylinder head screw - M6X8-GB70_1	12
3	420680176	Control box frame - C9Z-A19-B2	1
4	614901943	Power side post - C12V3-A1-B1	1
5		Power unit - 3.5kW	1
6	203204103	Flange nut - M8-GB6177	4
7	420040010	Anti-vibration pad - 6254E-A23	4
8	201101103	Cap head square neck bolt - M8X30-GB12	4
9	614901944	Main extending post - C12V3-A5-B1	1
10	201102035	Hex head full swivel screw - M14X30-GB5783	16
11	615068783	Crossbeam assembly - C12V3-A21	1
12	203103006	Hex locking nut - M8-GB889_1	4
13	615068786	Bracket assembly for guiding pulley - C12V3-A8-B2	2
14	202109030	Hex socket cylinder head screw - M8X25-GB70_1	4
15	203101008	Hex nut - M14-GB6170	32
16	204201007	Spring washer - D14-GB93	32
17	204101008	Flat washer - D14-GB95	32
18	410912511	Stronger plate for extending post - C12V3-A20 (optional, only usable for the total height of 4452mm)	2
19	201102035	Hex head full swivel screw - M14X40-GB5783	16
20	614901946	Secondary extending post - C12V3-A6-B1	1
21	420680096	Protective cover 2 - C9Z-A1-B9-1	1
22	202109017	Hex socket cylinder head screw - M6X10-GB70_1	4
23	614901945	Secondary post - C12V3-A2-B1	1
24	202111007	Hex socket flat head screw - M8X20-GB70_3	8
25	420130010	Round pad - 6214EKZ-A4-B4-C4	4
26	615035037	Lifting tray assembly - 6214EKZ-A4-B4	4
27	614013213B	Retractable arm - 6255E-A4-B3	4
28	614013212	Mid arm - 6255E-A4-B2	4
29	614013211B	Support arm - 6255E-A4-B1	4
30	204101006	Flat washer - D10-GB95	8
31	202109040	Hex socket cylinder head screw - M10X16-GB70_1	8
32	204301013	Circlip - D38-GB894_1	4
33	410901967	Semicircular teeth block - 6255E-A4-B5	4
34	202109085	Hex socket cylinder head screw - M12X30-GB70_1	12
35	410901744	Holder - 6254E-A1-B1-C6-V0	2
36	202110004	Hex socket button head screw - M8X12-GB70_2	4
37	612013002	Height-extension adapter - 6214EKZ-A4-B5	4
38	410049031B	Pin shaft - 6254E-A12	4
39	420680189	Protective ring 35 - C9ZV31-A10	1

FIG. 7 - ELECTRICAL




No.	Code	Description	QTY
T	320104002	Transformer (380V400V415V-24V)	1
T	320104001	Transformer (220V230V240V-24V)	1
QF	320801001	Circuit breaker (3Ph)	1
QF	320802001	Circuit breaker (1Ph)	1
QF1	320803001	Circuit breaker	1
QF2	320803003	Circuit breaker	1
KM	320901001	AC contactor	1
QS	320304001	Main switch	1
SQ1	320301002	Limit switch	1
SQ2	320301011	Limit switch	1
SQ3	320301003	Switch	1
	320503002	Wire terminals	1
SB1 SB2	320401042	Button	2
HL	321201001	Indicator light	1
	320505021	Wire terminal	1

FIG. 8 - CABLES



No.	Code	Description	QTY
1	615068782	Steel rope - C12V3-A7 L=11800mm	2
1	615068782	Steel rope - C12V3-A7 L=11800mm	2
3	203101012	Hex nut - M20-GB6170	8
4	204101011	Flat washer - D20-GB95	4
5	201201019	Expansion bolt - M19x200	10


FIG. 9 - CARRIAGE






No.	Code	Description	QTY
1	203103005	Hex locking nut - M6-GB889_1	2
2	410170101B	Ring for cylinder fixation - 6264-A24-B1	2
3	202109096	Hex socket cylinder head screw - M6X40-GB70_1	2
4	614901947	Carriage - C12V3-A3-B1	2
5	420680203	Slider - C12V3-A3-B5	8
6	420680203	Slider - C12V3-A3-B5	8
7	420680124	Protection rubber pad - 62B-A3-B11	2
8	202109031	Hex socket cylinder head screw - M8X30-GB70_1	4
9	210101018	Plastic protective cover - 80X80MM	2
10	410902399B	Pull rod - 6255E-A3-B4-C1-1	4
11	410150121	Pressure spring - 6254E-A2-B4	4
12	410901966	Teeth block - 6255E-A3-B6	4
13	206102013	Elastic post pin - D6X40-GB879	4
14	204301009	Circlip - D25-GB894_2	4
15	202111004	Hex socket flat head screw - M8X12-GB70_3	2
16	612056001	Shaft for downside pulley - C12-A1-B3	4
17	205101101	Bearing - 3520-SF-1X	4
18	410902109	Pulley - C9Z-A1-B2	4

FIG. 10 - DIMENSIONS

SYMMETRICAL



ASYMMETRICAL





LIMITED WARRANTY

The **Titan 2 Post lifts, 4 Post lifts and Bridge Jacks** are backed by a standard **1-year** replacement parts warranty and a **5-year** structural warranty from the date of purchase, to the original purchaser only. The **1-year** replacement parts warranty covers power units, hydraulic cylinders, and all other assembly components such as, but not limited to: turn plates, slip plates, cables, chains, valves, switches etc. This does not cover normal wear items such as, but not limited to: rubber lifting pads and nylon slide blocks. Titan Elite model lifts have been discontinued but still qualify under the same terms as shown above.

Titan 2 Post Master Series, SL-6600 Scissor Lifts and PREMIER Series 2 Post Lifts are backed by a **2-year** replacement parts warranty and a **5-year** structural warranty from the date of purchase, to the original purchaser only. The **2-year** replacement parts warranty covers power units, hydraulic cylinders, and all other assembly components such as, but not limited to: valves, switches, capacitors etc. This does not cover normal wear items such as, but not limited to: rubber lifting pads and rubber arm pads.

Titan Master Series 2 post lifts includes lifetime warranty on nylon slide blocks.

Titan 4 Post Master Series are backed by a **2-year** replacement parts warranty and a **6-year** structural warranty from the date of purchase, to the original purchaser only. The **2-year** replacement parts warranty covers power units, hydraulic cylinders, and all other assembly components such as, but not limited to: turn plates, slip plates, cables, chains, valves, switches etc. This does not cover normal wear items such as, but not limited to: rubber lifting pads and nylon slide blocks.

Titan Master Series Aluminum Deck Kit are backed by a **90 day** replacement.

Any and all lift cable adjustments are at owners expense and not covered under limited warranty.

Titan MRL-6000 Scissor lifts are backed by a standard **1-year** replacement parts warranty and a **5-year** structural warranty from the date of purchase, to the original purchaser only. The **1-year** replacement parts warranty covers power units, hydraulic cylinders, and all other assembly components such as, but not limited to: valves, switches, capacitors etc. This does not cover normal wear items such as but not limited to rubber lifting pads.

Titan ROT-4500 Rotisseries are backed by a standard **1-year** replacement parts warranty from the date of purchase, to the original purchaser only. The **1-year** replacement parts warranty covers components such as, but not limited to: hydraulic cylinders, caster assemblies, bearings etc. This does not cover normal wear items such as, but not limited to, mounting adapters.

Titan Standard Duty and Heavy Duty motorcycle lifts are backed by a standard **1-year** replacement parts warranty from the date of purchase, to the original purchaser only. The **1-year** replacement parts warranty covers power units, hydraulic cylinders, pneumatic cylinders, and all other assembly components such as, but not limited to: cables, caster wheels, valves, switches, wheel vises etc. This does not cover normal wear items such as, but not limited to: rubber wheel vise pads.

Titan Light Duty motorcycle lifts are warranted for replacement parts only to the original purchaser for a period of **90 days** from the date of purchase. This **90 day** replacement parts warranty covers items such as, but not limited to: hydraulic cylinder, casters, pedal assemblies, wheel vises etc. This does not cover normal wear items such as, but not limited to: rubber wheel vise pads.

Titan Bulldog Moto Cradle Wheel Chock is warranted for replacement parts, only to the original purchaser, for a period of **2-years** from the date of purchase.

XL Tool by Titan Wheel Service Machines and Helper Arm Assemblies are backed by a standard **1-year** replacement parts warranty from the date of purchase, to the original purchaser only. The **1-year** replacement parts warranty covers internal boards, motors, pneumatic cylinders, and all other assembly components such as, but not limited to: cabinet, switches, valves, fittings etc. This does not cover normal wear items such as but not limited to: rubber pads, jaw protectors, air hoses, quick nut assemblies.

Titan shop equipment products and accessories are warranted for replacement parts only to the original purchaser for a period of **90 days** from the date of purchase. This **90 day** replacement parts warranty covers products such as but not limited to: EZ -Mover Jacks, Mini Jacks, tie down products, wheel service accessories, Bulldog Moto Cradle Wheel Chock accessories, dollies, stands, Multi-purpose Jacks, replacement power units purchased as stand alone units, etc.

Titan TJ1T, FJ2T, and FJ3T are warranted for replacement parts only to the original purchaser for a period of **1 year** from the date of purchase.

All non-serialized items will require proof of purchase in the form of a sales receipt from an authorized Titan Lifts dealer showing the date of purchase for any warranty consideration.

For **all** warranty considerations, Titan Marketing, LLC will supply replacement parts only during the warranty period. The original purchaser is responsible for all shipping, handling, and any labor charges incurred. Hydraulic/Pneumatic cylinders may qualify for exchange under warranty if reported within the first 30 days from date of sale. After the first 30 days from date of sale, a seal kit and installation instructions will be sent for cylinder repairs. All defective parts must be returned to Titan for inspection and examination. Any parts that are found to be defective will be replaced or repaired to proper working order. Other items not listed above may be considered general wear parts and therefore, will not be covered under warranty. These warranties **do not** extend to **defects** caused by ordinary wear, abuse, misuse, shipping damage, improper installation, voltage or lack of required maintenance. Titan Marketing, LLC is **not** to be held responsible for any **failure** that results from an accident, purchaser/operator abuse, neglect, or failure to operate products in accordance with instructions provided in the owner's manual(s) supplied. Damage caused by rain, excessive humidity, corrosive environments or other contaminants are not covered under warranty. **THESE WARRANTIES DO NOT EXTEND TO ANY COSMETIC DEFECT NOT INTERFERING WITH EQUIPMENT FUNCTIONALITY OR ANY INCIDENTAL, INDIRECT, OR CONSEQUENTIAL LOSS, DAMAGE, OR EXPENSE THAT MAY RESULT FROM ANY DEFECT, FAILURE OR MALFUNCTION OF A TITAN MARKETING LLC PRODUCT OR THE BREACH OR DELAY IN PERFORMANCE OF THE WARRANTY.**

P.O. Box 7069 • Greenwood, IN 46142 • Ph. 888-908-4826 • Fx. 317-215-2770 • www.titanlifts.com

WARRANTY REGISTRATION

In order to utilize the warranty on this Titan Lifts product, you must register your product with us. The simplest way to do this is to visit [TITANLIFTS.COM/WARRANTIES](https://www.titanlifts.com/warranties) and submit your information online. If you prefer to send your information through the mail, please fill out the form below and send this page to us at :

**Titan Lifts
PO Box 7069
Greenwood, IN 46142**

EQUIPMENT MODEL: _____ SERIAL NUMBER: _____
TYPE OF POWER UNIT: _____ SERIAL NUMBER: _____
DATE OF PURCHASE: _____
PLACE PURCHASED: _____
NAME: _____
STREET: _____
CITY, STATE, ZIP: _____
PHONE: _____
EMAIL: _____

OPT OUT OF PROMOTIONS



In order to receive your warranty, return this card or visit [TITANLIFTS.COM/WARRANTIES](https://www.titanlifts.com/warranties) within 30 days.

 **WARNING** 

The warnings, precautions and instructions in this manual cannot cover all possible conditions and situations that may occur. The operator must understand that the operator must supply common sense and examine caution factors when using this product to determine safety in all circumstances being used.



TITAN MARKETING, LLC

PO Box 7069 Greenwood, IN 46142
1.888.908-4826 FAX (317) 215.2770
www.titanlifts.com

**Patent No.: US 8,104,588 B2
CA 2,729,670**

2/12/25