



WB-450 FACTORY CALIBRATION & RESET

- 1) Turn machine on
- 2) Press the following sequence of buttons to do a Factory calibration or Factory Reset
- 3) Press House key
- 4) Press DIS+
- 5) "Setup" appears
- 6) Press House 2 Times
- 7) Below appears
- 8) Left Right
- 9) "POS" "###"
- 10) Rotate shaft until "111" appears in right window
- 11) Hit mm/inch
- 12) Rotate shaft until "55" appears in right window
- 13) Hit mm/inch
- 14) Rotate shaft until "111" appears in right window
- 15) Hit mm/inch
- 16) Below appears
- 17) Left Right
- 18) "COD" "Set"
- 19) Hit House key
- 20) Below appears
- 21) Left Right
- 22) "###" "###"
- 23) Hold DIS+ until "46" appears in the left window
- 24) Hit House key
- 25) Below appears
- 26) Left Right
- 27) "B-A" "###"
- 28) Pull distance gauge out and put to flange – note distance on distance gauge
- 29) The number on the right must match the number noted on distance gauge
- 30) Change the number on the right by pressing DIS+ or DIS-
- 31) Hit House key
- 32) Below appears
- 33) Left Right
- 34) "EL1" "###"
- 35) Use DIS+ or ID- to change the number on the right to 007
- 36) Hit House key
- 37) Hit House key
- 38) Until the reset is completed with a series of beeps
- 39) Turn the machine off and back on